





BHMS-101

HotPlate Magnetic Stirrer

Thank you for Choosing Biolab products. Please read the "Operating Instructions" and "Warranty" before operating this unit to assure proper operation.

CO2 Incubator

Index

| 1. | Installation Instructions | 03 |
|----|--|-----|
| 2. | Operating Procedure | 03 |
| 3. | Troubleshooting and Error Code Information | .04 |



01 Installation Instructions

1. Unpack and place the magnetic stirrer on a stable and temperature resistant surface.

2. Ensure good working environment free of explosive, hazardous and inflammable substances.

3. Place the stirrer at >10cm distance from the wall and other units if using multiple units together.

4. Keep away from the effect of high magnetic fields.

5. Do not cover the device. Ensure that the main power supply cable does not touch the hotplate.

6. Ensure that the label indicated the correct voltage before connecting the device to power supply.

7. Do not operate the unit with a damaged power cord.

8. Connect the power cord to the unit in the socket provided.

9. Turn on the power.

02 Operating Procedure

- 1. Switch power ON and the instrument starts to self-check.
- 2. Mount a vessel with stirring liquid and suitable stirring bar on to the work plate.

3. Set the temperature by rotating the temperature control knob Heat slowly to desired setting.

4. Set the target speed by rotating the speed control knob Stir slowly to desired setting.

3

CO2 Incubator

03 Troubleshooting and Error Code Information

| Fault code | Problem description | Cause | Solution |
|---------------|---------------------------------|-------------------------------|---|
| | No operating response | No power supply | Check and connect the power supply before turning on the power again. |
| E01 | | Fuse damaged | Replace the fuse |
| | | Connection failure | Open the instrument, check all connections and reconnect. |
| | The instrument does not heat | Target temperature is not set | Set target temperature, and temperature indicator lamp is ON |
| E02 | | Driver board failure | Replace the driver board |
| | | Heating element failure | Replace the heating element |
| | Instrument does not stir | Target speed is not set | Set target speed, and speed indicator lamp is ON |
| E03 | | Driver board failure | Replace the driver board |
| | | Power panel failure | Replace the power panel |
| | | Motor failure | Replace the motor component |

4



BIOLAB SCIENTIFIC LTD. 3660 Midland Avenue, Suite 300, Toronto, Ontario M1V 0B8 Canada Email: contact@biolabscientific.com Tel: +1 707 533 1445 Website: www.biolabscientific.com